

# Key to install

- 1) The pin out used for the CB plug is for the Colt 355. Yours may vary.
- 2) Separate the wire at the back of the intercom plug and run it to and from the switch.
- 3) Switch used is a DPDT momentary switch which I mounted above the Radio switch on handle bar.
- 4) Add a 1000pf capacitor between the microphone ground to common ground on intercom connector for feed back.
- 5) make sure you tie all common grounds to one point.



