

INSTALLATION INSTRUCTIONS

Auxiliary Air Hose Set (62600-24820)




Fig. 2




Fig. 4




Fig. 1




Fig. 3

Letter	Qty	Description
A	1	Switch
B	1	Hose

Auxiliary Air Hose Set 62600-24820

1. Determine the place to install the switch by removing the fairing lid and case from left side fairing. (Fig. 1)
2. Outline with tape along those lines of 30.2mm (1.19in.) x 26.2mm (1.03in.) as shown Fig. 2.
3. Drill holes along the inner sides of the tape as shown in the Fig. 1 and use a cutter or the like to cut it down.
4. Remove burrs with a file and correct the hole size with a cutter.
5. Install the switch (A).
6. Connect the switch coupler to the coupler, both of which have the same wire colors of red/green and red/yellow, extended from the wire harness. (Fig.3)
7. Install the case with four screws.
8. Remove the cap and connect the air hose (B) to the place shown in the Fig. 4. The air hose is now ready to use.

CAUTION: Do not use the air compressor continuously for more than 5 minutes or the system become damaged.